

# Install Pre-Assembled Manifold



The sprinkler wire needs to have at least one more wire strand than the number of valves being installed

[www.irrigationdepot.ca](http://www.irrigationdepot.ca)

