

Figure A

- Turn water off.
- Remove old nozzle (if necessary).
- Place filter in stem with open end up (see Figure A).
- Screw nozzle on.




Figure B

- **Pattern Adjustment**
Turn the top of the nozzle to the desired spray pattern, 25°–360° (see Figure B).

Distance Adjustment

The radius adjustment screw in the center of the nozzle top reduces overspray up to 25%.




Figure C

- Adjust ratchet head stem to the desired starting point (see Figure C).

NOZZLES